

BuffPro/Nuvite - 3 Step Metal Polishing Instructions

Step 1 (Initial)

BuffPro Heavy Cutting Wool Pad and Nuvite NuShine II F9 grade polish

Apply 1-2 7" lines of Nuvite polish. Go over with Buffer at lowest speed right after pressing trigger

Using the buffer, spread over area to be polished (24"-36" x 24"-36")

Increase speed: 5-6 on speed control dial

Pressure: Firm

Number of times over material: Until polish is mostly gone

Number of passes: 2-3

Wipe down surface with Mineral Spirits when done

Step 2 (Intermediate)

BuffPro Polishing Wool Pad and Nuvite NuShine II C grade polish

Apply 1-2 7" lines of Nuvite polish. Go over with Buffer at lowest speed right after pressing trigger

Using the buffer, spread over area to be polished (24"-36" x 24"-36")

Increase speed: 3-4 on speed control dial

Pressure: Medium

Number of times over material: Until polish is mostly gone

Number of passes: 1-2

Wipe down surface with Mineral Spirits when done

Step 3 (Final)

BuffPro SLW Finishing Wool Pad and Nuvite NuShine II S grade polish

Speed: 1-2 on speed control dial - Maximum

Pressure: Very light

Number of times over material: 1-2 up and down motions

Number of passes: 1

Wipe down surface with Mineral Spirits when done